

CHANGING THE BATTERY

Batteries for data loggers are provided by the Vermont Immunization Program free of charge.



Step 1 Pause the data logger then unplug it and download the data. **Step 2** Place the data logger face down. Carefully peel off the sticker printed with the calibration information (A) along with the thick white sticker that covers the battery (B) and put it aside. This reveals the battery cover (C). **Do not** throw the stickers away.



Step 3 Using a coin or a paperclip, unlock and remove the battery cover (D). **Step 4** Pop-out the old battery (E) and dispose of it properly.



Step 5 Place the new battery, positive (+) side up, in the reservoir and press it into place (F). **Step 6** Replace the cover and twist to lock (G). **Step 7** Replace the thick white sticker on top of the battery cover (H), that you removed in Step 2.



Step 8 Apply the clear plastic sticker (I) over the top of the entire calibration label (J) that you removed in Step 2, You are now ready to return the data logger to the assigned unit and follow the same instructions to start it as when you would after your weekly download. **If the data logger is not displaying anything download it and restart.**